

70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817 Installation Instructions

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1817
INSTALLATION
INSTRUCTIONS

1985-Up Chrysler / Plymouth / Dodge / Jeep / Eagle Wire Harness

1-800-221-0932 www.metraonline.com © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground



REV. 111704

NOTE-1:

For vehicles with the amplified sound systems including the Infinity sound systems: In order for the factory amplifier to turn on and off, connect the blue wire on the 70-1817 harness to the aftermarket radios amplifier turn on wire.

NOTE-2:

For all vehicles: The manufacturer does not supply a lead for ground in the factory wiring so the 70-1817 does not have a black wire. The ground wire from your aftermarket radio should be connected to a grounded piece of the sub-dash. Many vehicles come with a flat metal strap bolted to the back of the factory radio. This strap can also be used for the aftermarket radio's ground