

# 70-9003 INSTALLATION **INSTRUCTIONS**

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

#### For all vehicles except MINI:

Using the long red wire included with the harness. connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

#### For MINI only:

Using the long red wire included with the harness. insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION

REV. 02/01/10 INST70-9003



# 70-9003 INSTALLATION INSTRUCTIONS

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

#### For all vehicles except MINI:

Using the long red wire included with the harness. connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

### For MINI only:

Using the long red wire included with the harness. insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION

REV. 02/01/10 INST70-9003



# **70-9003 INSTALLATION INSTRUCTIONS**

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

#### For all vehicles except MINI:

Using the long red wire included with the harness. connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

### For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION

REV. 02/01/10 INST70-9003

# 70-9003 INSTALLATION INSTRUCTIONS

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

#### For all vehicles except MINI:

Using the long red wire included with the harness, connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY

#### For MINI only:

Using the long red wire included with the harness. insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION

REV. 02/01/10 INST70-9003



## 70-9003 INSTALLATION **INSTRUCTIONS**

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

### For all vehicles except MINI:

Using the long red wire included with the harness, connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

### For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION



### 70-9003 INSTALLATION INSTRUCTIONS

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

### For all vehicles except MINI:

Using the long red wire included with the harness, connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

### For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION



### 70-9003 INSTALLATION INSTRUCTIONS

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

### For all vehicles except MINI:

Using the long red wire included with the harness, connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

### For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION



### 70-9003 INSTALLATION INSTRUCTIONS

### 2002-Up BMW / VOLKSWAGEN 2002-2006 MINI 2007-2008 MINI CONVERTIBLE

### For all vehicles except MINI:

Using the long red wire included with the harness, connect the fuse tap (gold in color) to a 12 volt accessory source in your fuse box. Cut the other end to desired length and connect it to your aftermarket radio ONLY.

#### For MINI only:

Using the long red wire included with the harness, insert the silver end into pin sixteen of the harness. (See back). Cut the other end to desired length and connect it to your aftermarket radio ONLY.

1-800-221-0932 www.metraonline.com © COPYRIGHT 2010 METRA ELECTRONICS CORPORATION

REV. 02/01/10 INST70-9003

REV. 02/01/10 INST70-9003

REV. 02/01/10 INST70-9003

REV. 02/01/10 INST70-9003















