



Kia Sportage LX (with base radio*) 2017-2019*

*Visit MetraOnline.com for up-to-date vehicle specific applications.

† Base radio is a non-touchscreen radio

KIT FEATURES

- ISO DIN radio provision with pocket
- Painted scratch-resistant matte black

KIT COMPONENTS

- A) Radio trim panel • B) Radio brackets • C) Pocket • D) (2) #8 x 3/8" Phillips screws




TABLE OF CONTENTS

Dash Disassembly	2
Kit Preparation	3
Kit Assembly	3

WIRING & ANTENNA CONNECTIONS (sold separately)

Wiring Harness: 70-7304

Antenna Adapter: Not required

Steering wheel control interface: ASWC-1


TOOLS REQUIRED

- Panel removal tool • Phillips screwdriver


CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

DASH DISASSEMBLY


1. Unclip and slide the top of the center console back slightly. (Figure A)
2. Unclip and remove the panel on the end of the passenger side of the dash, then remove (1) Phillips screw exposed. (Figure B)
3. Unclip and remove the dash panel above the glove box. (Figure C)



(Figure A)




(Figure B)




(Figure C)

4. Remove (2) Phillips screws securing the radio display and a/c vent panel, then unclip and remove the panel. (Figure D)
5. Remove (4) Phillips screws securing the radio. Slide the radio out, then unplug and remove the radio. (Figure E)

Continue to Kit Preparation



(Figure D)




(Figure E)

KIT PREPARATION

Radio Trim Panel Installation

From the factory radio trim panel:


1. Remove (4) Phillips screws securing the inner trim panel, then remove the panel. (Figure A)



(Figure A)

To the factory radio trim panel:

2. Secure the 99-7379B radio trim panel to the panel using with the factory screws. (Figure B)




(Figure B)


Continue to Kit Assembly

KIT ASSEMBLY

1. Secure the radio brackets to the pocket using the (2) #8 x 3/8" Phillips screws provided. (Figure A)
2. Remove the metal DIN sleeve and trim ring from the aftermarket radio.
3. Slide the radio into the bracket/pocket assembly, then secure it to the assembly using the screws supplied with the radio. (Figure B)
4. Locate the factory wiring harness and antenna connector in the dash and complete all necessary connections to the radio. Metra recommends using the proper mating adapter from Metra and/or AXCESS. Test the radio for proper operation.
5. Secure the radio assembly to the dash using the factory screws.
6. Reassemble the dash in reverse order of disassembly to complete the installation.



(Figure A)



(Figure B)



99-7378B
INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 7:00 PM

Sunday: 10:00 AM - 4:00 PM



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.edu or call 386-672-5771 for more information and take steps toward a better tomorrow.



**Metra recommends MECP
certified technicians**